Qubino

The **INNOVATIVE** and **SMALLEST**

Flush 1 relay

ORDERING CODE	Z-WAVE FREQUENCY
ZMNHAA2	868,4 MHz
ZMNHAA3	921,4 MHz
ZMNHAA4	908,4 MHz
ZMNHAA5	869,0 MHz
ZMNHAA6	916,0 MHz

This Z-Wave module is used for switching on or off the electrical device (e.g. light, fan, etc ...). The module can be controlled either through Z-wave network or through the wall switch.
The module is designed to be mounted inside a “flush mounting box”, hidden behind a traditional wall switch.
Module measures power consumption of electrical device and supports connection of digital temperature sensor. It is designed to act as repeater in order to improve range and stability of Z-wave network.

Supported switches

Module supports **mono-stable** switches (push button) and **bi-stable** switches. The module is factory set to operate with bi-stable switches.

Installation

- Before the installation disconnect power supply.
- Connect the module according to electrical diagram.
- Locate the antenna far from metal elements (as far as possible).
- Do not shorten the antenna.

Danger of electrocution!

- Module installation requires a great degree of skill and may be performed only by a qualified and licensed electrician.
- Even when the module is turned off, voltage may be present on its terminals. Any works on configuration changes related to connection mode or load must be always performed by disconnected power supply (disable the fuse).

Note!

Do not connect the module to loads exceeding recommended values. Connect the module only in accordance to the below diagrams. Improper connections may be dangerous.

Package contents

- Flush 1 relay

Electrical diagram 230VAC



Notes for the diagram:

N Neutral lead
L Live lead
Q Output for electrical device
I3 Input for switch /push button or sensor
I2 Input for switch /push button or sensor
I1 Input for switch /push button
TS Terminal for digital temperature sensor (only for Flush 1 relay module compatible digital temperature sensor, which must be ordered separately).

Electrical diagram 24VDC



Notes for the diagram:

N + 24VDC
L - 24VDC
Q Output for electrical device
I3 Input for switch /push button or sensor
I2 Input for switch /push button or sensor
I1 Input for switch /push button
TS Terminal for digital temperature sensor (only for Flush 1 relay module compatible digital temperature sensor, which must be ordered separately).



S Service button (used to add or remove module from the Z-Wave network).

Durability of the module depends on applied load. For resistive load (light bulbs, etc.) and 10A current consumption of each individual electrical device, the durability exceeds 100 000 switches of each individual electrical device.

Module Inclusion (Adding to Z-wave network)

- Connect module to power supply (with temperature sensor connected - if purchased),
- bring module within maximum 1 meter (3 feet) of the main controller,
- enable add/remove mode on main controller
- auto-inclusion (30 minutes after connected to power supply) or
- press service button **S** for more than 2 second or
- press push button **I1** three times within 3s (3 times change switch state within 3 seconds).

Module Exclusion/Reset (Removing from Z-Wave network)

- Connect module to power supply
- bring module within maximum 1 meter (3 feet) of the main controller,
- enable add/remove mode on main controller
- press service button **S** for more than 6 second or
- press push button **I1** five times within 3s (5 times change switch state within 3 seconds) in the first 60 seconds after the module is connected to the power supply.

By this function all parameters of the module are set to default values and own ID is deleted
If service button S is pressed more than 2 and less than 6 second module is excluded, but configuration parameters are not set to default values.

Association

Association enables Flush 1 relay module to transfer commands inside Z-Wave network directly (without main controller) to other Z-Wave modules.

Associated Groups:
Group 1: basic on/off (triggered at change of the output Q state and reflecting its state) up to 16 nodes.
Group 2: basic on/off (triggered at change of the input I2 state and reflecting its state) up to 16 nodes.
Group 3: basic on/off (triggered at change of the input I3 state and reflecting its state) up to 16 nodes.
Group 4: default reporting group (reserved for the main controller).

Configuration parameters

Parameter no. 1 – Input 1 switch type
Available configuration parameters (data type is 1 Byte DEC):
- default value 1
- 0 mono-stable switch type (push button)
- 1 bi-stable switch type

Parameter no. 2 – Input 2 contact type
Available configuration parameters (data type is 1 Byte DEC):
- default value 0
- 0 NO (normally open) input type
- 1 NC (normally close) input type

Parameter no. 3 – Input 3 contact type
Available configuration parameters (data type is 1 Byte DEC):
- default value 0
- 0 NO (normally open) input type
- 1 NC (normally close) input type

Parameter no. 10 - Activate / deactivate functions ALL ON/ALL OFF
Available configuration parameters (data type is 1 Byte DEC):
- default value 255
- 255 - ALL ON active, ALL OFF active
- 0 - ALL ON is not active ALL OFF is not active
- 1 - ALL ON is not active ALL OFF active
- 2 - ALL ON active ALL OFF is not active

Flush 1 relay module responds to commands ALL ON / ALL OFF that may be sent by the main controller or by other controller belonging to the system.

Parameter no. 11 - Automatic turning off relay after set time
Available configuration parameters (data type is 2 Byte DEC):
- Default value 0
- 0 - Auto OFF disabled
- 1 – 65535 = 0,01second – 655,35 seconds Auto OFF enabled with define time, step is 10mseconds.

Parameter no. 30 - Saving the state of the relay after a power failure
Available configuration parameters (data type is 1 Byte DEC):
- default value 0
- 0 – Flush 1relay module saves its state before power failure (it returns to the last position saved before a power failure)
- 1 - Flush 1relay module does not save the state after a power failure, it returns to "off" position.

Parameter no. 40 – Power reporting in Watts on power change

Set value means percentage, set value from 0 - 100=0% - 100%. Available configuration parameters (data type is 1 Byte DEC):

- default value 3
- 0 – Reporting Disabled
- 1 – 100 = 1% - 100% Reporting enabled Power report is send (push) only when actual power in Watts in real time changes for more than set percentage comparing to previous actual power in Watts, step is 1%.

NOTE: if power changed is less than 1W, the report is not send (pushed), independent of percentage set.

Parameter no. 42 – Power reporting in Watts by time interval

Set value means time interval (0 – 65535) in seconds, when power report is send.

Available configuration parameters (data type is 2 Byte DEC):

- default value 300 (power report in Watts is send each 300s)
- 0 – Reporting Disabled
- 1 – 65535 = 1second – 65535 seconds. Reporting enabled. Power report is send with time interval set by entered value.

Technical Specifications

Power supply	110 - 230 VAC ±10% 50/60Hz, 24-30VDC
Rated load current of AC output (resistive load)*	1 X 10A / 230VAC
Rated load current of DC output (resistive load)	1 X 10A / 30VDC
Output circuit power of AC output (resistive load)	2300W (230VAC)
Output circuit power of DC output (resistive load)	240W (24VDC)
Power measurement accuracy	P=5-50W, +/-3W P>50W, +/-3%
Digital temperature sensor range (sensor must be ordered separately)	-50 ~ +125°C
Operation temperature	-10 ~ +40°C
Distance	up to 30 m indoors (depending on building materials)
Dimensions (W x H x D)	41,8 x 36,8 x 15,4mm
Weight	28g
Electricity consumption	0,4W
For installation in boxes	Ø ≥ 60mm or 2M
Switching	Relay

* In case of load other than resistive, pay attention to the value of cos φ and if necessary apply load lower than the rated load. Max current for cos φ=0,4 is 3A at 250VAC, 3A at 24VDC L/R=7ms.

Z-Wave Device Class:

BASIC_TYPE_ROUTING_SLAVE
GENERIC_TYPE_SWITCH_BINARY
SPECIFIC_TYPE_POWER_SWITCH_BINARY

Z-Wave Supported Command Classes:

COMMAND_CLASS_BASIC
COMMAND_CLASS_SWITCH_BINARY
COMMAND_CLASS_SWITCH_ALL
COMMAND_CLASS_METER_V3
COMMAND_CLASS_SENSOR_MULTILEVEL_V3
COMMAND_CLASS_MULTI_CHANNEL_V2
COMMAND_CLASS_POWERLEVEL
COMMAND_CLASS_ASSOCIATION
COMMAND_CLASS_CONFIGURATION
COMMAND_CLASS_MANUFACTURER_SPECIFIC
COMMAND_CLASS_VERSION
COMMAND_CLASS_MARK
COMMAND_CLASS_BASIC

Endpoint 1 (I2):
Device Class:
GENERIC_TYPE_SENSOR_BINARY
SPECIFIC_TYPE_NOT_USED
Command Classes:
COMMAND_CLASS_SENSOR_BINARY
COMMAND_CLASS_BASIC

Endpoint 2 (I3):
Device Class:
GENERIC_TYPE_SENSOR_BINARY
SPECIFIC_TYPE_NOT_USED
Command Classes:
COMMAND_CLASS_SENSOR_BINARY
COMMAND_CLASS_BASIC

This product can be included and operated in any Z-Wave network with other Z-Wave certified devices from any other manufacturers. All constantly powered nodes in the same network will act as repeaters regardless of the vendor in order to increase reliability of the network.

Important disclaimer

Z-Wave wireless communication is inherently not always 100% reliable, and as such, this product should not be used in situations in which life and/or valuables are solely dependent on its function.

Warning!

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new once, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.
This user manual is subject to change and improvement without notice.

Qubino
Goap d.o.o. Nova Gorica
Ulica Klementa Juga 007
5250 Solkan
Slovenia

E-mail: info@qubino.com
Tel: +386 5 335 95 00
Web: www.qubino.com

Date: 8.12.2014
Document: Qubino_Flush 1 relay user manual_V6.3_eng